

NOTE: APPLY A MODERATE TAP TO PROJECTED END OF TOGGLE TO BEGIN COUNTERCLOCKWISE LOOSENING.

PULSER ASSEMBLY KIT P/N IDM-1  
INCLUDES: PULSER BRACKET ASSEMBLY P/N IDM-1-1  
DRIVE HUB ASSEMBLY P/N IDM-1-2

DRIVE HUB ASSEMBLY  
2 POLE MAGNET P/N IDM-1-2  
(INCLUDED)

INDEX

COVER



PULSER BRACKET ASSEMBLY P/N IDM -1-1  
WITH FORM 'A' REED SWITCH (INCLUDED)

PAN HEAD SCREWS #10-24 X 3/8 LG  
SUPPLIED WITH METER

FILLISTER HEAD #10-24 X 1/2 LG  
SUPPLIED WITH METER

#### INSTALLATION INSTRUCTIONS

1. REMOVE INDEX COVER
2. REMOVE INDEX
3. REMOVE BRASS TOGGLE (SEE NOTE)
4. INSTALL DRIVE HUB ON METER SHAFT (#6-32 THREAD) WITH PIN FACING OUTWARD
5. USING PAN HD SCREWS LOOSELY ATTACH PULSER BRACKET ASSEMBLY TO METER BODY
6. MOUNT INDEX WITH SLOTTED FITTINGS TO ITEM 5. SCREWS
7. ALIGN INDEX AND TIGHTEN SCREWS
8. MOUNT INDEX COVER USING (3) FILLISTER HEAD SCREWS

IMPORTANT!! GUIDE SWITCH WIRES AROUND INDEX TO CLEAR GEARS. CONTINUE GUIDING WIRES AND EXIT COVER THROUGH BOTTOM LUG OR HOLE ABOVE RIGHT SCREW

FOR USE ON:

METER MANUFACTURER: ITRON  
MODELS: METRIS 250 OR 400A